RESPIRATORS HFM UNIVERSAL SERIES - IS

V-400

Reusable Half Face Mask with Particulate & OV Filter

Product available with below approval



CM/L-0003748172 Half Face Mask



Particle Filter

IS 15323 CM/L-0007905889 Gas Filter



FEATURES AND BENEFITS



Light weight body

- Made from soft thermoplastic elastomer, skin friendly
- Low maintenance
- Minimum hindrance in working



Exhalation vent valve

 Allows efficient escape of CO, & hot exhaled air



Latex-free elastic

- Braided textile elastic is skin friendly
- Lasts longer without deforming



Single filter

- Low profile & provides more peripheral view
- Does not hinder while working and makes the use more convenient



VENUS V-400 + V7400 P2

Combo HFM + RF



Half mask with Particulate filter Solid particles 1000 ppm or 12 X OEL whichever is lower

Item # 15058



VENUS V-400+V7400 A1 P1

HFM + RF

Half mask with Organic & Particulate filter Carbon Tetrachloride (CCI_A) 1000 ppm or 4 X OEL whichever is lower

Item # 15059

Size options

















Neck Strap

TPE Material



4 point strap tightening with head cradle

Front pull strap tightening gives the required ergonomic fit



Adjustable head harness

- Distributes weight evenly
- Provides head support and good fit



Threaded cartridge

Tape easy to fit and replace



VENUS V-7400 A1 RF - Gas Filter Organic Filter For V-400 A1P1 Carbon Tetrachloride (CCI₄)

Item # 17038



1000 ppm or 20 X OEL whichever is lower



VENUS V-7400 P2 RF - Particulate Filter

Solid particles & Liquid Item # 17039



VENUS V-7400 P1 RF - Pre Filter

Solid particles Item # 17040



4 X OEL

APPLICATION EXAMPLES

Battery Chemical Cold storage Engineering **Foundries** Mining Automobile

Lead handling, acid handling Laboratory, Coating, Bonding, Handling Warehouses Welding, Powder coating, Painting

Foundry areas Drilling Painting, Powder coating Petrochemicals Agrochemical Paints Pharmaceuticals Ships Sewage

Solvent handling, Maintenance department Pesticides spraying Paint spray, Mixing, Resins Bulk drugs, Material handling Tank deaning Drains





Technical Datasheet

Venus V-400

Single filter for HFM



ISI Approved

VENUS V-400+V7400 P2 Combo

HFM + RF Half mask with Particulate filter Solid particles 1000 ppm or 12 X OEL whichever is lower Item # 110532501

VENUS V-400+V7400 A1 P1 Combo

HFM + RF Half mask with Organic & Particulate filter Carbon Tetrachloride (CCI4) 1000 ppm or 4 X OEL whichever is lower Item # 110532601

Technical Specifications

Size: Medium (M). **Approval Standards:**

> o IS 14746: Half Face Mask o IS 15322: Particulate Filter

Material: TPE (Thermoplastic Elastomer).



- 1. **Lightweight Body:** Made from soft, skin-friendly TPE material.
- 2. Exhalation Vent Valve: Efficiently expels CO₂ and hot air.
- 3. Latex-Free Elastic: Durable, skin-friendly braided elastic.
- 4. **Single Filter Design:** Low profile for improved peripheral vision.
- 5. **4-Point Strap Tightening:** Adjustable straps with head cradle for stability.
- 6. Adjustable Head Harness: Evenly distributes weight for added comfort.
- 7. **Press Fit Cartridge System:** Easy and secure filter attachment.





Benefits of V-400

- 1. Lightweight Body: Comfortable for long use and minimizes work hindrance.
- 2. Exhalation Vent Valve: Enhances breathing comfort and reduces heat buildup.
- 3. Latex-Free Elastic: Ensures a secure fit and long-lasting performance.
- 4. **Single Filter Design**: Reduces obstruction and enhances convenience.
- 5. **4-Point Strap Tightening**: Provides an ergonomic, secure fit.
- 6. Adjustable Head Harness: Reduces strain and ensures a stable fit.
- 7. Press Fit Cartridge System: Simplifies maintenance and ensures reliability.

Cautions and Limitations

- 1. Ensure a proper fit before use; an improper seal can reduce protection.
- 2. Not suitable for oxygen-deficient environments or confined spaces.
- 3. Replace filters regularly or when breathing resistance increases.
- 4. Avoid use in environments with unknown or highly toxic contaminants.
- 5. Store in a clean, dry place away from direct sunlight and harmful chemicals.
- 6. Follow all user instructions for assembly, use, and maintenance.

User Instructions

- 1. Fit Check: Ensure a secure seal by adjusting the straps and harness for a snug fit.
- 2. Filter Installation: Attach filters firmly using the press-fit cartridge system.
- 3. **Usage**: Wear the mask in environments specified for its protection level (e.g., particulate, gas, or both).
- 4. **Maintenance**: Clean regularly with a damp cloth and mild detergent. Do not use harsh chemicals.
- 5. **Storage**: Keep in a clean, dry place, away from direct sunlight and contaminants.
- 6. **Replacement**: Replace filters when breathing becomes difficult or as per manufacturer's guidelines.

Applications:

1. Automobile, Petrochemicals & Agrochemical

- Painting, Powder coating, Solvent handling, Maintenance department, Pesticides spraying
- 2. Battery
 - Lead handling, acid handling
- 3. Chemical & Cold storage
 - Laboratory, Coating, Bonding, Handling, Warehouses
- 4. Engineering & Mining
 - Welding, Powder coating, Painting, Drilling
- 5. Foundries
 - Foundry areas
- 6. Paints
 - Paint spray, Mixing, Resins
- 7. Pharmaceuticals
 - Bulk drugs, Material handling
- 8. Ships & Sewage
 - Tank cleaning, Drains



J.THADHANI & CO.

New #12/ Old #28, Stringers Street, Chennai - 600001, Tamilnadu, India.



044 - 4262 5223

